



120° INSTALLATION FOR 15XX & 16XX



Apollo models 1500, 1550ETL, 1600, 1650ETL can be installed to open a swing gate up to 120°. An alternate pivot position must be used to accomplish this. All measurements are taken from the center of the hinge. If the pivot arm is to be attached to the hinge post, the pivot arm must be modified to accommodate actuator clearance.

The gate will swing a little faster than in a normal installation.



Gate Closed



Gate Opened

120° INSTALLATION FOR 15XX & 16XX



Apollo models 1500, 1550ETL, 1600, 1650ETL can be installed to open a swing gate up to 120°. An alternate pivot position must be used to accomplish this. All measurements are taken from the center of the hinge. If the pivot arm is to be attached to the hinge post, the pivot arm must be modified to accommodate actuator clearance.

The gate will swing a little faster than in a normal installation.

